## 6.2 Shortcuts

## Functions – Softkeys – Shortcut keys

Control key:	
CTRL + P	For screenshots – Storage location: Commissioning (password) – System data – HMI data – Logs – Screenshots
CTRL + L	Language switchover
CTRL + C	Сору
CTRL + X	Cut
CTRL + V	Paste
CTRL + Y	Redo (editor functionality)
CTRL + Z	Undo – max. five lines in the editor (editor functionality)
CTRL + A	Select all (editor functionality)
CTRL + INLXT	Go to start of program
CTRL + END	Go to end of program
CTRL + ALT + S	Save complete archive – NCK/PLC/drives/HMI
CTRL + ALT + D	Backup log files on USB or CompactFlash card
CTRL + E	Control energy

CTRL + M	Maximum simulation speed
CTRL + F	Search in all screen forms  Wildcards "?" and ""*" can be used in search screen forms. "?" stands for any character, "*" for any number of any characters.
Miscellaneous:	
Shift + Sinser	Commenting out of cycles and direct editing of programGUIDE cycles
Shift + END	Select up to end of block
Shift + INDICATE TO THE SHIP OF THE SHIP O	Select up to start of line
ALT + INDEXT	Jump to start of line
ALT + S	Enter Asian characters
-	Calculator function
HELP	Help function
END	Jump to end of line

Simulation and simultaneous recording:		
AFV4	Move	
Shift + ▲ / ▼	Rotate in 3D display	
AV	Move section	
CTRL + ▲ / ▼	Override +/- (simulation)	
CTRL + S	Single block on/off (simulation)	
Insert key:		
NSERT	It brings you into the Edit mode for text boxes or into the Selection mode of combo boxes and toggle fields. You can exit this without making any changes by pressing Insert again.	
NSERT	Undo function,as long as no Input key is pressed or no data has already been transferred to the fields.	
Toggle key:		
SELECT	You can directly switch between toggle fields using the Toggle key (Select) without having to open them. With Shift-Toggle you can switch through these in the reverse direction.	
Cursor key:		
<b>4 •</b>	Open/close directory	
	Open/close program	
	Open/close cycle	